


即插即用 (P2P) 网络摄像机

快速安装说明书

一、了解你的摄像机



1: 网络接口 2: TF 卡接口 3: 电源接口

二、下载安装 Yoosee 手机端 App

根据手机类型前往苹果 APP Store 或安卓 Google Play 搜索 Yoosee, 或前往 www.yoosee.co 下载并安装 “Yoosee” 手机端 app, 根据提示完成注册并登陆 Yoosee。

三、添加摄像机

方式一：通过 WIFI 联网添加

将手机 WiFi 连接到无线路由器 (由于摄像机 WiFi 不支持 5G 网络, 请确认手机连接的 WiFi 是 2.4G 网络), 打开 Yoosee

手机端 App, 在设备列表右上角点击添加按钮 “+”, 选择智能联机, 此时 App 将自动识别手机接入的 WiFi SSID, 输入 WiFi 密码, 点击下一步, 按照向导完成后面操作, 摄像机成功接入 WiFi 后, 输入设备密码, 保存即完成添加。



方式二：通过有线网络添加

摄像机接通电源后, 把网线一端连接摄像机网络接口, 另一端连接路由器 LAN 接口 (确保路由器开启 DHCP 功能)。打开 Yoosee 手机端 App, 在设备列表右上角点击添加按钮 “+”, 选择手动添加, 输入设备名字、设备 ID、设备密码, 保存即完成添加。



四、使用 Yoosee 访问摄像机

- ①查看实时视频: 点击摄像机缩略图上的播放按钮, 可以查看摄像机的实时视频, 滑动画面可以控制摄像机转动。
- ②回放录像文件: 点击摄像机列表条目空白处, 在弹出的选项里点击回放进入录像回放界面, 默认检索摄像机当天的录像文件, 选择文件进行播放。
- ③设置选项可以设置摄像机不同参数。

五、无线传感器学习对码

摄像机 (部分型号) 可以与相同频率 (433M 或 315M) 的无线传感器 (门磁、烟感、人体 Pir 等) 学习配对, 构建无线报警系统; 例如把门磁学习在大厅防区中的 1 号通道: 在设备列表中点击条目空白处, 在弹出菜单中选择设置 > 防区 > 大厅 > 通道 1, 点击确定, 同时触发门磁, 将会出现 “学习成功” 的提示, 在报警设置中, 开启 “接收报警信息”, 此时对摄像机进行布防操作, 布防成功后, 一旦门磁被触发, 摄像机将向手机端 App 推送报警消息。

六、常见问题

- ① Q: 添加设备时, app 没有提示发现新设备
A: 请检查摄像机和手机是否在同一个局域网内; 请检查摄像机的网络指示灯是否常亮; 若摄像机和手机不在同一个局域网内, 建议用 ID 号手动添摄像机;
- ② Q: 查看实时视频时, 提示密码错误
A: 请检查添加摄像机时设置的远程访问密码是否正确, 若不正确请在摄像机列表条目中选择编辑重新设置远程访问密码; 若忘记摄像机的远程访问密码, 建议按 “Reset” 键将设备恢复出厂默认值 (默认为空, 首次添加摄像机时需创建新密码, 否则将不能进行远程访问);
- ③ Q: 设备列表中提示设备离线
A: 请检查摄像机是否正常联网, 检查网络指示灯是否常亮; 请检查路由器网络是否正常;

- ④ Q: 红外遥控器无法控制摄像机转动
A: 请检查红外遥控器与手机的耳机插孔连接是否正常; 请调整红外遥控器方向, 对准摄像机的红外接收器; 部分些手机需要将音量键调至最大;

- ⑤ Q: 回放录像时未能搜索到录像文件
A: 请检查 SD 卡是否损坏; 请检查录像文件的检索时间, 检查摄像机的系统时间;

- ⑥ Q: 摄像机无法连接 WIFI
A: 确认输入 WIFI 密码是否正确; 摄像机不支持 5G 网络, 请将手机连接至 2.4G WIFI 网络

七、获取更多信息

本快速操作指南将指导您快速使用您的网络摄像机, 如需获取更多的帮助信息, 可以向厂家寻求技术支持。




Android



ios

Quick Guide for Yoosee

Step 1. Camera Interface



1: Network 2: SD card 3: Power

Step 2. Download and Install Yoosee APP


Go to the Apple APP Store or Android Google Play search Yoosee, or visit www.yoosee.co to download Yoosee APP. When you finish installation, please log-in.

Step 3. Add Camera on Yoosee

方式一: By WIFI


Connect your phone to WIFI first, and make sure it's 2.4G WIFI, since camera doesn't support 5G WIFI. On the Device

List interface, please click the "+" button and choose "Smartlink", enter the WIFI code, when it connects, enter and save the Device Code, then it's done.



By Wired Network

Power on and connect the network cable. On the Device List interface, click "+" button and choose "Manual", enter and save Device Name & Device ID & Device Password, then it's done.



Step 4. Access Camera on Yoosee

- ① Real-time video. Click the Play button on the camera image, you can view the real-time video, and slide the screen to control camera rotation.
- ② Playback video. Click the blank on the camera list, choose Playback.
- ③ Setting. Click the blank on the camera list, choose Setting.

Step 5. Use with Wireless Sensor

Some cameras can use with wireless sensor (like magnet sensor) in the same frequent (433MHz or 315MHz), making a wireless alarm system.

For example, place a magnet sensor in the hall as channel 1: Click the blank on the camera list, choose Setting > Area > Hall > Channel 1, it will show Success. In alarm setting, "receive alarm message". Once the magnet sensor was triggered, camera will send alert messages to your phone.

Step 6. FAQ

- ① Q: When add the camera, no device was found.
A: Check whether your phone and camera are in the same LAN; Check whether your network lamp keeps on; If your camera and phone are not in the same LAN, please add your camera by manual.
- ② Q: When view the real-time video, it said password error.
A: Check your remote access password, you can re-set your password in Edit item; If you forget password, please press "Reset" button to restore factory defaults (The default is empty, when you add your camera, you need to enter a new password, or else you can't do remote access).
- ③ Q: It says device offline in device list.
A: Check whether your camera connects with the Internet well, whether the network lamp keeps on; Check your router.

④ Q: The remote control doesn't use.

A: Check whether your remote control connects well with the headphone jack of your cellphone. Please aim your remote control at the camera infrared signal receiver. Some cellphone should turn Volume Max.

⑤ Q: Video file can't find when playback.

A: Check your SD card; Check retrieval time of the video file and system time of your camera.

⑥ Q: Camera can't access WIFI.

A: Check the WIFI password; Check it's 2.4G WIFI, camera can't support 5G WIFI.

Step 7. obtain more information

More information, technical support from the factory will help.



Android



ios